SCOPE SETTER



Set it up right the first time!

Scope Setter is a bench-top tool that enables you to level your scope reticle and align the scope rings relative to true level on an actual Picatinny rail. Reticle level is extremely important for long range accuracy—especially when using ballistic drop compensating (BDC) scopes. In addition, having both scope ring bases aligned to an actual Picatinny rail is absolutely essential to repeatable installation on a firearm. Scope Setter can also be used to preset your clamp-on style scope level.

- Take-down design—all components stored safely inside—fits easily in your range bag
- Takes the guesswork and frustration out of reticle leveling during scope installation
- Mil Spec Picatinny rail properly orients your rings relative to each other
- Unattached precision level allows you to use the same level on rail and scope
- Virtually eliminate reticle cant during scope installation
- Allows you to adjust clamp-on style scope levels
- Designed and Manufactured in the USA
- Non skid foot pads



0

SCOPE SETTE





INVENTURE PO Box 190026

Boise, ID 83719-0026 208 863 6033

© 2017 Inventure Engineering and Machine, LLC


inventeng.com



SCOPE SETTER



OPEN SCOPE SETTER AND REMOVE LEVEL



2 ASSEMBLE AND LEVEL SCOPE SETTER





LEVEL SCOPE AND TORQUE SCOPE RINGS





*Complete and detailed instructions are provided with each Scope Setter purchased.

CAUTION: When handling any firearm please use safe gun handling practices. Always verify the magazine and chamber are unloaded. Consult your owner's manual for complete safety instructions on making your firearm safe for scope installation.